

Split-Jaw™ Smart Meter

- Measures 0.9-200AAC
- Measures 1.3-750VAC
- Measures 2.1-1000VDC
- Measures 0.0-9999Ω
- Audible continuity
- Data hold
- Integral lead storage
- Replaceable test leads
- Auto power off
- Low battery indication
- 2-year warranty



Specifications

| 61-096 | | |
|------------|-------------------------------|------|
| AC Voltage | 1.3 - 750 V | 1.5% |
| DC Voltage | 1.8 - 1000 V -0.6 - 1000 V | 1.0% |
| AC Current | 0.6 - 200.0A | 3.0% |
| Resistance | 0 - 2000 Ω | 1.0% |

*Note: Jaw opening is 0.6 in. (16mm) - up to 1/0 copper cable.

| Description | Cat. No. |
|------------------------|----------|
| Split-Jaw™ Smart Meter | 61-096 |

Includes: Test Leads.

Circuit Breaker Finders

- Fully automatic operation
- Positively identifies circuit breakers and fuses without service interruption
- Self calibrating
- Visual and audible indicators
- 2-year warranty



61-534
w/GFCI receptacle tester



| Description | Cat. No. |
|---|----------|
| Circuit Breaker Finder w/Digital Receiver & GFCI Circuit Tester | 61-534 |
| Circuit Breaker Finder w/Analog Receiver | 61-532 |

TL-532A



61-532



Alligator clip adapter allows connections to exposed wiring.



Lighting adapter allows connection to light fixtures.

Specifications

| | 61-532 | 61-534 |
|---------------------|---------------|---------------|
| Operating Voltage | 100 - 140 VAC | 100 - 250 VAC |
| Operating Frequency | 47 - 63 Hz | 47 - 63 Hz |

VoltAware™ Non-Contact Voltage Tester

- Indicates presence of voltage from 40-1000VAC
- Visual indication of voltage
- Selectable audible indication of voltage
- Sleek, compact design
- Green LED indicates power on
- Low battery indicator
- Battery replacement (AAA size)
- 2-year warranty



Convenient button turns audible voltage indication on or off.



| Description | Cat. No. |
|---------------------------------------|----------|
| VoltAware™ Non-Contact Voltage Tester | 61-025 |

VoltSensor™ Non-Contact Voltage Tester

- Tests for voltage from 40-600VAC
- Audible and visual indication
- Locates breaks along live insulated wires
- Tests for energized circuits
- Battery replacement (LR44/61-201)
- 1-year warranty



| Description | Cat. No. |
|---|----------|
| Volt-Sensor® Non-Contact Voltage Tester | 61-063 |

Continuity Tester


- Checks continuity of dead circuits and ground on conduit systems and identifies wires in multi-wire cables
- Light signal indicates completed circuit
- Bulb-in end can serve as flashlight
- Pocket clip functions as probe
- Removable 4-ft. test lead with alligator clip
- 1-year warranty



| Description | Cat. No. |
|-------------------|----------|
| Continuity Tester | 61-030 |

E-Z Check® Circuit Tester

- Tests for correct wiring, open ground, reverse polarity, open hot, open neutral, hot on neutral, hot and ground reversed with open hot, and ground fault interruption in 3-wire, 120VAC circuits
- No-slip ergonomic design maximizes comfort
- Premium neon lamps prevent false readings
- Tough, impact-resistant case
- 2-year warranty



61-051

| Description | Cat. No. |
|-------------------------------------|----------|
| E-Z Check® Plus GFCI Circuit Tester | 61-051 |
| E-Z Check® Circuit Tester | 61-035 |

Receptacle Testers

- Warns against faulty wiring in 3-wire receptacles
- For use on 120VAC circuits
- 1-year warranty


61-501



| Description | Cat. No. |
|------------------------|----------|
| GFCI Receptacle Tester | 61-501 |
| Receptacle Tester | 61-500 |

Test-Glo™ Circuit Tester

- Industrial-quality tester checks voltage from 80V to 600V AC/DC
- Neon test lamp at front of probe
- Resistors reduce voltage reaching leads
- 24-in. lead – rated 1,000V
- 1-year warranty



| Description | Cat. No. |
|--------------------------|----------|
| Test-Glo™ Circuit Tester | 61-040 |